

Unobtainium Supply Co
When it's NLA, who do you call?



MIRROR CAP INSTALLATION TIPS

Rev. A

Effective: 12-FEB-2017

Unobtainium Supply Co.

523 Longley Rd

Groton, MA 01450

978.448.2110

www.UnobtainiumSupply.com

MIRROR CAP INSTALLATION TIPS:

The Ferrari design isn't great for retention. However, there are some things you can do to ensure they don't get lost:

1. Check to make sure the ridges in the mirror base fit fully into the grooves in the mounting tabs. If necessary use a small file to tweak the groove to ensure fit.
2. If the fit is just a bit loose, try heating in near boiling water to soften the cap & expand it slightly to tighten the fit.
3. Install with a small amount of black silicone on the tabs to ensure it doesn't accidentally come loose.